



Description:

On Halloween, carved pumpkins are often placed in the front yard or in front of the door. In the sand-colored Halloween pumpkins of Europalms a smiling face is already carved. A red LED is attached to the centre of the floor inside the pumpkin and glows permanently when switched on by the ON/OFF switch on the battery compartment. A manual control by cable is also possible.

Logistique

EAN / GTIN: 4026397676747
Poids: 0,15 kg
Longueur: 0.20 m
Largeur: 0.18 m
Hauteur: 0.20 m

Caractéristiques:

- Possibilité de fonctionnement sur batterie/piles
- Rouge lumineux
- L'article est livré avec prêt à poser

Données techniques:

Classe de protection:	SK III
Branchement électrique:	Pile/batterie Tramite
Batterie:	3 x pile bouton 1,5 V LR44 alcaline au manganèse intégré
Effet:	Rouge lumineux
Matériau:	Plastique
Couleur:	Orange

Saison:	Halloween
Dimension:	Largeur : 18 cm Profondeur : 16 cm Hauteur : 19,5 cm
Poids:	0,14 kg

Contenu de la livraison:

1 x figurine
1 x Mode d'emploi
3 x Batterie