

Halloween Dancing Singer, 145cm

The perfect hip swing for your Halloween party

Réf. : 83316086

GTIN: 4026397633948



L'article n'est plus disponible.

Halloween Dancing Singer, 145cm

The perfect hip swing for your Halloween party

Réf. : 83316086

GTIN: 4026397633948

Caractéristiques:

- Hook arms and legs in the stand
- Activation of the animation and the sound effect by integrated microphone
- Optional with wired control possible
- Operation with three 1.5V AA batteries (not included in delivery)
- Possibilité de fonctionnement sur batterie/piles
- Effet sonore
- Hanches avec effet de mouvement
- Assemblage simple