

OMNITRONIC PM-3010 Pro DJ mixer

PRO 3+1-channel DJ mixer with matrix

Art. No.: 10006850 GTIN: 4026397380453











The article is no longer in our assortment.

Features:

- Matrix input assignment: each channel with routing facility of all input sources as desired
- 3 channels with gain control, 3-band equalizer, cue button, smooth and durable fader and 10-digit LED level meter
- 1 DJ microphone channel with 3-band equalizer, level control, on air and talkover selector
- Color illuminated rotary controls and rubber buttons
- Prefader listening to all input channels and the master output via adjustable headphones output, with cue mix/split function
- Replaceable crossfader with VCA technology for crossfading between input channels, with assignment switches, adjustable curve and reverse function
- Master control and stereo LED level meter
- Master level switchable 0.75 V or 1.5 V
- Separately controllable monitor and zone outputs
- Separately controllable session input to connect a further mixer
- 2 recording outputs, independent of the master and with on/off switch for DJ microphone signals
- Inputs: 4 x line (stereo RCA); 3 x phono/line (stereo RCA), switchable; 1 x DJ microphone (XLR/6.3 mm jack), 2 x microphone (6.3 mm jack) and 1 x headphones (6.3 mm jack)
- Outputs: 1 x master (stereo XLR/stereo RCA), 1 x zone (6.3 mm stereo jack, bal.), 1 x booth (stereo RCA), 2 x record (stereo RCA) and 1 x session (stereo RCA)
- Operation via supplied power unit

Technical specifications:

Power consumption:	35,00 W
Frequency range:	20 - 20000 Hz

Logistic

EAN / GTIN: 4026397380453

Weight: 5,10 kg Length: 0.46 m Width: 0.28 m Heigth: 0.17 m

Depth: 22 cm Height: 11 cm	Dimensions:	Width: 34 cm
Weight: 4,60 kg Power supply: 230 V AC, 50 Hz via supplied power unit Inputs:		Depth: 22 cm
Power supply:	Weight:	
via supplied power unit Inputs: DJ microphone: combined XLR/6.3 mm jack (1/4*) (bal.) MIC 1, 2: 6.3 mm jack (1/4*) (bal.) Minimum input voltage: 1 mV RMS LINE/PHONO 1-3: stereo RCA Minimum input voltage: 150 mV RMS (line), 3 mV RMS (phono) AUX 1-4: stereo RCA Minimum input voltage: 150 mV RMS Outputs: 0.75 WRMS MASTER: stereo XLR/stereo RCA Output voltage: 0.75 V/1.5 V RMS (switchable) ZONE: 6.3 mm stereo jack Output voltage: 0.75 V RMS BOOTH: stereo RCA Output voltage: 0.75 V RMS REC: stereo RCA Output voltage: 0.75 V RMS Headphones output: 6.3 mm jack (min. 8 ohms) Tone control (DJ microphone): 1 x high: 1 x high: -12 dB to +12 dB/ 10 kHz, ±1 dB 1 x middle: -12 dB to +12 dB/ 10 Hz, ±1 dB 1 x low: -12 dB to +12 dB/ 100 Hz, ±1 dB 3 x high: -26 dB to +12 dB/ 100 Hz, ±1 dB 3 x		
Inputs: DJ microphone: combined XLR/6.3 mm jack (1/4*) (bal.) MIC 1, 2: 6.3 mm jack (1/4*) (bal.) Minimum input voltage: 1 mV RMS LINE/PHONO 1-3: stereo RCA Minimum input voltage: 150 mV RMS (line), 3 mV RMS (phono) AUX 1-4: stereo RCA Minimum input voltage: 150 mV RMS Outputs: MASTER: stereo XLR/stereo RCA Output voltage: 0.75 V/1.5 V RMS (switchable) ZONE: 6.3 mm stereo jack Output voltage: 0.75 V RMS BOOTH: stereo RCA Output voltage: 0.75 V RMS REC: stereo RCA Output voltage: 0.75 V RMS REC: stereo RCA Output voltage: 0.75 V RMS Tone control (DJ microphone): 1 x high: -12 dB to +12 dB/ 10 kHz, ±1 dB 1 x middle: -12 dB to +12 dB/ 100 Hz, ±1 dB 1 x low: -12 dB to +12 dB/ 10 kHz, ±1 dB 1 x low: -15 dB Tone control (channel 1-3): 3 x high: -26 dB to +12 dB/ 1 kHz, ±1 dB 3 x middle: -26 dB to +12 dB/ 100 Hz, ±1 dB S/N ratio: -75 dB Distortion: 0.03%		<u> </u>
DJ microphone: combined XLR/6.3 mm jack (1/4¹) (bal.) MIC 1, 2: 6.3 mm jack (1/4¹) (bal.) Minimum input voltage: 1 mV RMS LINE/PHONO 1-3: stereo RCA Minimum input voltage: 150 mV RMS (line), 3 mV RMS (phono) AUX 1-4: stereo RCA Minimum input voltage: 150 mV RMS Outputs: MASTER: stereo XLR/stereo RCA Output voltage: 0.75 V/1.5 V RMS (switchable) ZONE: 6.3 mm stereo jack Output voltage: 0.75 V RMS BOOTH: stereo RCA Output voltage: 0.75 V RMS REC: stereo RCA Output voltage: 0.75 V RMS Tone control (DJ microphone): 1 x high: 1 2 dB to +12 dB/10 kHz, ±1 dB 1 x low: 1 2 dB to +12 dB/100 Hz, ±1 dB Tone control (channel 1-3): 3 x high: -26 dB to +12 dB/10 kHz, ±1 dB 3 x middle: -26 dB to +12 dB/100 Hz, ±1 dB 3 x middle: -26 dB to +12 dB/100 Hz, ±1 dB 3 x low: -26 dB to +12 dB/100 Hz, ±1 dB 3 x low: -26 dB to +12 dB/100 Hz, ±1 dB 3 x low: -26 dB to +12 dB/100 Hz, ±1 dB 3 x low: -26 dB to +12 dB/100 Hz, ±1 dB 3 x low: -26 dB to +12 dB/100 Hz, ±1 dB 3 x low: -26 dB to +12 dB/100 Hz, ±1 dB 3 x low: -26 dB to +12 dB/100 Hz, ±1 dB 3 x low: -26 dB to +12 dB/100 Hz, ±1 dB 3 x low: -26 dB to +12 dB/100 Hz, ±1 dB 3 x low: -26 dB to +12 dB/100 Hz, ±1 dB	Inputs:	на варрива ролгог али
MIC 1, 2: 6.3 mm jack (1/4*) (bal.) Minimum input voltage: 1 mV RMS LINE/PHONO 1-3: stereo RCA Minimum input voltage: 150 mV RMS (line), 3 mV RMS (phono) AUX 1-4: stereo RCA Minimum input voltage: 150 mV RMS Outputs: MASTER: stereo XLR/stereo RCA Output voltage: 0.75 V 1.5 V RMS (switchable) ZONE: 6.3 mm stereo jack Output voltage: 0.75 V RMS BOOTH: stereo RCA Output voltage: 0.75 V RMS REC: stereo RCA Output voltage: 0.75 V RMS Headphones output: 6.3 mm jack (min. 8 ohms) Tone control (DJ microphone): 1x high: 1 x high: -12 dB to +12 dB/ 10 kHz, ±1 dB 1 x winddle: -12 dB to +12 dB/ 10 kHz, ±1 dB 1 x low: -12 dB to +12 dB/ 100 Hz, ±1 dB Talkover attenuation: -15 dB Tone control (channel 1-3): 3 x high: -26 dB to +12 dB/ 10 kHz, ±1 dB 3 x middle: -26 dB to +12 dB/ 100 Hz, ±1 dB		combined XLR/6.3 mm jack (1/4") (bal.)
Minimum input voltage: 1 mV RMS LINE/PHONO 1-3: stereo RCA Minimum input voltage: 150 mV RMS (line), 3 mV RMS (phono) AUX 1-4: stereo RCA Minimum input voltage: 150 mV RMS Outputs: MASTER: MASTER: stereo XLR/stereo RCA Output voltage: 0.75 V/1.5 V RMS (switchable) ZONE: 6.3 mm stereo jack Output voltage: 0.75 V RMS BOOTH: stereo RCA Output voltage: 0.75 V RMS REC: stereo RCA Output voltage: 0.75 V RMS Headphones output: 6.3 mm jack (min. 8 ohms) Tone control (DJ microphone): 1 x high: 1 x high: -12 dB to +12 dB/ 10 kHz, ±1 dB 1 x middle: -12 dB to +12 dB/ 10 kHz, ±1 dB 1 x low: -12 dB to +12 dB/ 10 kHz, ±1 dB Talkover attenuation: -15 dB Tone control (channel 1-3): 3 x high: -26 dB to +12 dB/ 10 kHz, ±1 dB 3 x middle: -26 dB to +12 dB/ 100 Hz, ±1 dB 3 x low: -26 dB to +12 dB/ 100 Hz, ±1 dB <tr< td=""><td>-</td><td></td></tr<>	-	
Minimum input voltage: 150 mV RMS (line), 3 mV RMS (phono) AUX 1-4: stereo RCA Minimum input voltage: 150 mV RMS Outputs:	Minimum input voltage:	
AUX 1-4: stereo RCA Minimum input voltage: 150 mV RMS Outputs: MASTER: stereo XLR/stereo RCA Output voltage: 0.75 V/1.5 V RMS (switchable) ZONE: 6.3 mm stereo jack Output voltage: 0.75 V RMS BOOTH: stereo RCA Output voltage: 0.75 V RMS REC: stereo RCA Output voltage: 0.75 V RMS REC: stereo RCA Output voltage: 0.75 V RMS Headphones output: 6.3 mm jack (min. 8 ohms) Tone control (DJ microphone): 1 x high: -12 dB to +12 dB/ 10 kHz, ±1 dB 1 x middle: -12 dB to +12 dB/ 100 Hz, ±1 dB 1 x low: -12 dB to +12 dB/ 100 Hz, ±1 dB Talkover attenuation: -15 dB Tone control (channel 1-3): 3 x high: -26 dB to +12 dB/ 10 kHz, ±1 dB 3 x middle: -26 dB to +12 dB/ 10 kHz, ±1 dB 3 x low: -26 dB to +12 dB/ 100 Hz, ±1 dB 3 x low: -26 dB to +12 dB/ 100 Hz, ±1 dB 3 x low: -26 dB to +12 dB/ 100 Hz, ±1 dB S/N ratio: >75 dB Distortion: 0.03%	LINE/PHONO 1-3:	stereo RCA
Minimum input voltage: 150 mV RMS Outputs: Stereo XLR/stereo RCA Output voltage: 0.75 V/1.5 V RMS (switchable) ZONE: 6.3 mm stereo jack Output voltage: 0.75 V RMS BOOTH: stereo RCA Output voltage: 0.75 V RMS REC: stereo RCA Output voltage: 0.75 V RMS Headphones output: 6.3 mm jack (min. 8 ohms) Tone control (DJ microphone): 12 dB to +12 dB/ 10 kHz, ±1 dB 1 x middle: -12 dB to +12 dB/ 10 kHz, ±1 dB 1 x low: -12 dB to +12 dB/ 100 Hz, ±1 dB Talkover attenuation: -15 dB Tone control (channel 1-3): -26 dB to +12 dB/ 10 kHz, ±1 dB 3 x middle: -26 dB to +12 dB/ 10 kHz, ±1 dB 3 x low: -26 dB to +12 dB/ 100 Hz, ±1 dB S/N ratio: >75 dB Distortion: 0.03%	Minimum input voltage:	150 mV RMS (line), 3 mV RMS (phono)
Outputs: MASTER: stereo XLR/stereo RCA Output voltage: 0.75 V/1.5 V RMS (switchable) ZONE: 6.3 mm stereo jack Output voltage: 0.75 V RMS BOOTH: stereo RCA Output voltage: 0.75 V RMS REC: stereo RCA Output voltage: 0.75 V RMS Headphones output: 6.3 mm jack (min. 8 ohms) Tone control (DJ microphone): 1x high: 1 x high: -12 dB to +12 dB/10 kHz, ±1 dB 1 x middle: -12 dB to +12 dB/100 Hz, ±1 dB 1 x low: -12 dB to +12 dB/100 Hz, ±1 dB Tone control (channel 1-3): 3 x high: 3 x middle: -26 dB to +12 dB/100 Hz, ±1 dB 3 x low: -26 dB to +12 dB/100 Hz, ±1 dB S/N ratio: >75 dB Distortion: 0.03%	AUX 1-4:	stereo RCA
MASTER: stereo XLR/stereo RCA Output voltage: 0.75 V/1.5 V RMS (switchable) ZONE: 6.3 mm stereo jack Output voltage: 0.75 V RMS BOOTH: stereo RCA Output voltage: 0.75 V RMS REC: stereo RCA Output voltage: 0.75 V RMS Headphones output: 6.3 mm jack (min. 8 ohms) Tone control (DJ microphone): 1 x high: 1 x high: -12 dB to +12 dB/ 10 kHz, ±1 dB 1 x low: -12 dB to +12 dB/ 10 NHz, ±1 dB 1 x low: -15 dB Tone control (channel 1-3): 3 x high: 3 x middle: -26 dB to +12 dB/ 10 kHz, ±1 dB 3 x low: -26 dB to +12 dB/ 100 Hz, ±1 dB S/N ratio: >75 dB Distortion: 0.03%	Minimum input voltage:	150 mV RMS
Output voltage: 0.75 V/1.5 V RMS (switchable) ZONE: 6.3 mm stereo jack Output voltage: 0.75 V RMS BOOTH: stereo RCA Output voltage: 0.75 V RMS REC: stereo RCA Output voltage: 0.75 V RMS Headphones output: 6.3 mm jack (min. 8 ohms) Tone control (DJ microphone): 1 x high: 1 x high: -12 dB to +12 dB/ 10 kHz, ±1 dB 1 x low: -12 dB to +12 dB/ 100 Hz, ±1 dB 1 x low: -15 dB Tone control (channel 1-3): 3 x high: 3 x middle: -26 dB to +12 dB/ 10 kHz, ±1 dB 3 x low: -26 dB to +12 dB/ 100 Hz, ±1 dB S/N ratio: >75 dB Distortion: 0.03%	Outputs:	
ZONE: 6.3 mm stereo jack Output voltage: 0.75 V RMS BOOTH: stereo RCA Output voltage: 0.75 V RMS REC: stereo RCA Output voltage: 0.75 V RMS Headphones output: 6.3 mm jack (min. 8 ohms) Tone control (DJ microphone): 1 x high: -12 dB to +12 dB/ 10 kHz, ±1 dB 1 x middle: -12 dB to +12 dB/ 100 Hz, ±1 dB 1 x low: -12 dB to +12 dB/ 100 Hz, ±1 dB Talkover attenuation: -15 dB Tone control (channel 1-3): 3 x high: -26 dB to +12 dB/ 10 kHz, ±1 dB 3 x middle: -26 dB to +12 dB/ 10 kHz, ±1 dB 3 x low: -26 dB to +12 dB/ 10 kHz, ±1 dB 3 x low: -26 dB to +12 dB/ 10 kHz, ±1 dB S/N ratio: >75 dB Distortion: 0.03%	MASTER:	stereo XLR/stereo RCA
Output voltage: 0.75 V RMS BOOTH: stereo RCA Output voltage: 0.75 V RMS REC: stereo RCA Output voltage: 0.75 V RMS Headphones output: 6.3 mm jack (min. 8 ohms) Tone control (DJ microphone): 1 x high: 1 x middle: -12 dB to +12 dB/ 10 kHz, ±1 dB 1 x low: -12 dB to +12 dB/ 100 Hz, ±1 dB Talkover attenuation: -15 dB Tone control (channel 1-3): -26 dB to +12 dB/ 10 kHz, ±1 dB 3 x middle: -26 dB to +12 dB/ 10 kHz, ±1 dB 3 x low: -26 dB to +12 dB/ 100 Hz, ±1 dB S/N ratio: >75 dB Distortion: 0.03%	Output voltage:	0.75 V/1.5 V RMS (switchable)
BOOTH: stereo RCA Output voltage: 0.75 V RMS REC: stereo RCA Output voltage: 0.75 V RMS Headphones output: 6.3 mm jack (min. 8 ohms) Tone control (DJ microphone): 1 x high: -12 dB to +12 dB/ 10 kHz, ±1 dB 1 x middle: -12 dB to +12 dB/ 1 kHz, ±1 dB 1 x low: -12 dB to +12 dB/ 100 Hz, ±1 dB Talkover attenuation: -15 dB Tone control (channel 1-3): 3 x high: -26 dB to +12 dB/ 1 kHz, ±1 dB 3 x middle: -26 dB to +12 dB/ 100 Hz, ±1 dB 3 x low: -26 dB to +12 dB/ 100 Hz, ±1 dB S/N ratio: >75 dB Distortion: 0.03%	ZONE:	6.3 mm stereo jack
Output voltage: 0.75 V RMS REC: stereo RCA Output voltage: 0.75 V RMS Headphones output: 6.3 mm jack (min. 8 ohms) Tone control (DJ microphone): -12 dB to +12 dB/ 10 kHz, ±1 dB 1 x middle: -12 dB to +12 dB/ 1 kHz, ±1 dB 1 x low: -12 dB to +12 dB/ 100 Hz, ±1 dB Talkover attenuation: -15 dB Tone control (channel 1-3): -26 dB to +12 dB/ 10 kHz, ±1 dB 3 x middle: -26 dB to +12 dB/ 100 Hz, ±1 dB 3 x low: -26 dB to +12 dB/ 100 Hz, ±1 dB S/N ratio: >75 dB Distortion: 0.03%	Output voltage:	0.75 V RMS
REC: stereo RCA Output voltage: 0.75 V RMS Headphones output: 6.3 mm jack (min. 8 ohms) Tone control (DJ microphone): -12 dB to +12 dB/ 10 kHz, ±1 dB 1 x middle: -12 dB to +12 dB/ 1 kHz, ±1 dB 1 x low: -12 dB to +12 dB/ 100 Hz, ±1 dB Talkover attenuation: -15 dB Tone control (channel 1-3): -26 dB to +12 dB/ 10 kHz, ±1 dB 3 x middle: -26 dB to +12 dB/ 1 kHz, ±1 dB 3 x low: -26 dB to +12 dB/ 100 Hz, ±1 dB S/N ratio: >75 dB Distortion: 0.03%	BOOTH:	stereo RCA
Output voltage: 0.75 V RMS Headphones output: 6.3 mm jack (min. 8 ohms) Tone control (DJ microphone): -12 dB to +12 dB/ 10 kHz, ±1 dB 1 x high: -12 dB to +12 dB/ 1 kHz, ±1 dB 1 x low: -12 dB to +12 dB/ 100 Hz, ±1 dB Talkover attenuation: -15 dB Tone control (channel 1-3): -26 dB to +12 dB/ 10 kHz, ±1 dB 3 x high: -26 dB to +12 dB/ 1 kHz, ±1 dB 3 x low: -26 dB to +12 dB/ 100 Hz, ±1 dB S/N ratio: >75 dB Distortion: 0.03%	Output voltage:	0.75 V RMS
Headphones output: Tone control (DJ microphone): 1 x high: -12 dB to +12 dB/ 10 kHz, ±1 dB 1 x middle: -12 dB to +12 dB/ 1 kHz, ±1 dB 1 x low: -12 dB to +12 dB/ 100 Hz, ±1 dB Talkover attenuation: -15 dB Tone control (channel 1-3): 3 x high: -26 dB to +12 dB/ 10 kHz, ±1 dB 3 x middle: -26 dB to +12 dB/ 10 kHz, ±1 dB 3 x low: -26 dB to +12 dB/ 100 Hz, ±1 dB 5/N ratio: >75 dB Distortion: 0.03%	REC:	stereo RCA
Tone control (DJ microphone): 1 x high: -12 dB to +12 dB/ 10 kHz, ±1 dB 1 x middle: -12 dB to +12 dB/ 1 kHz, ±1 dB 1 x low: -12 dB to +12 dB/ 100 Hz, ±1 dB Talkover attenuation: -15 dB Tone control (channel 1-3): 3 x high: -26 dB to +12 dB/ 10 kHz, ±1 dB 3 x middle: -26 dB to +12 dB/ 1 kHz, ±1 dB 3 x low: -26 dB to +12 dB/ 100 Hz, ±1 dB S/N ratio: >75 dB Distortion: 0.03%	Output voltage:	0.75 V RMS
1 x high: -12 dB to +12 dB/ 10 kHz, ±1 dB 1 x middle: -12 dB to +12 dB/ 1 kHz, ±1 dB 1 x low: -12 dB to +12 dB/ 100 Hz, ±1 dB Talkover attenuation: -15 dB Tone control (channel 1-3): -26 dB to +12 dB/ 10 kHz, ±1 dB 3 x middle: -26 dB to +12 dB/ 1 kHz, ±1 dB 3 x low: -26 dB to +12 dB/ 100 Hz, ±1 dB S/N ratio: >75 dB Distortion: 0.03%	Headphones output:	6.3 mm jack (min. 8 ohms)
1 x middle: -12 dB to +12 dB/ 1 kHz, ±1 dB 1 x low: -12 dB to +12 dB/ 100 Hz, ±1 dB Talkover attenuation: -15 dB Tone control (channel 1-3): -26 dB to +12 dB/ 10 kHz, ±1 dB 3 x high: -26 dB to +12 dB/ 1 kHz, ±1 dB 3 x middle: -26 dB to +12 dB/ 100 Hz, ±1 dB S/N ratio: >75 dB Distortion: 0.03%	Tone control (DJ microphone):	
1 x low: -12 dB to +12 dB/ 100 Hz, ±1 dB Talkover attenuation: -15 dB Tone control (channel 1-3): -26 dB to +12 dB/ 10 kHz, ±1 dB 3 x high: -26 dB to +12 dB/ 1 kHz, ±1 dB 3 x middle: -26 dB to +12 dB/ 100 Hz, ±1 dB S/N ratio: >75 dB Distortion: 0.03%	1 x high:	-12 dB to +12 dB/ 10 kHz, ±1 dB
Talkover attenuation: -15 dB Tone control (channel 1-3): -26 dB to +12 dB/ 10 kHz, ±1 dB 3 x high: -26 dB to +12 dB/ 1 kHz, ±1 dB 3 x middle: -26 dB to +12 dB/ 100 Hz, ±1 dB 3 x low: -26 dB to +12 dB/ 100 Hz, ±1 dB S/N ratio: >75 dB Distortion: 0.03%	1 x middle:	-12 dB to +12 dB/ 1 kHz, ±1 dB
Tone control (channel 1-3): 3 x high: -26 dB to +12 dB/ 10 kHz, ±1 dB 3 x middle: -26 dB to +12 dB/ 1 kHz, ±1 dB 3 x low: -26 dB to +12 dB/ 100 Hz, ±1 dB S/N ratio: >75 dB Distortion: 0.03%	1 x low:	-12 dB to +12 dB/ 100 Hz, ±1 dB
3 x high: 3 x high: -26 dB to +12 dB/ 10 kHz, ±1 dB 3 x middle: -26 dB to +12 dB/ 1 kHz, ±1 dB 3 x low: -26 dB to +12 dB/ 100 Hz, ±1 dB S/N ratio: >75 dB Distortion: 0.03%	Talkover attenuation:	-15 dB
3 x middle: -26 dB to +12 dB/ 1 kHz, ±1 dB 3 x low: -26 dB to +12 dB/ 100 Hz, ±1 dB S/N ratio: >75 dB Distortion: 0.03%	Tone control (channel 1-3):	
3 x low: -26 dB to +12 dB/ 100 Hz, ±1 dB S/N ratio: >75 dB Distortion: 0.03%	3 x high:	-26 dB to +12 dB/ 10 kHz, ±1 dB
S/N ratio: >75 dB Distortion: 0.03%	3 x middle:	-26 dB to +12 dB/ 1 kHz, ±1 dB
Distortion: 0.03%	3 x low:	-26 dB to +12 dB/ 100 Hz, ±1 dB
	S/N ratio:	>75 dB
Dimensions (WxHxD): 340 x 220 x 110 mm	Distortion:	0.03%
	Dimensions (WxHxD):	340 x 220 x 110 mm