

Halloween Dancing Singer, 145cm

The perfect hip swing for your Halloween party

Art.n.: 83316086
GTIN: 4026397633948



Halloween Dancing Singer, 145cm

The perfect hip swing for your Halloween party

Art.n.: 83316086
GTIN: 4026397633948

Features :

- Hook arms and legs in the stand
- Activation of the animation and the sound effect by integrated microphone
- Optional with wired control possible
- Operation with three 1.5V AA batteries (not included in delivery)
- Funzionamento a pila/batteria ricaricabile possibile
- Effetto sonoro
- Hips con effetto movimento
- Facile da montare